This Document is Hosted by: www.oldwillknottscales.com

SALTER®

1052

Digital Kitchen Scale
Balance Numérique de Cuisine
Báscula de Cocina Digital

Instruction Manual

Thank you for purchasing a Salter® Kitchen Scale. Your Salter® scale is an example of superior design and craftsmanship. Please read this instruction manual carefully before use. Keep these instructions handy for future reference.

Merci de votre achat d'une balance de cuisine Salter®. Votre balance Salter® est un exemple de design et de travail supérieurs. Veuillez lire attentivement votre manuel d'instructions avant d'utiliser l'appareil. Conservez ces instructions à portée de la main à titre de référence.

Gracias por comprar una báscula de cocina Salter®. Su báscula Salter® es un ejemplo de diseño y mano de obra superiores. Antes de usarla, sírvase leer con atención este manual de instrucciones. Guarde estas instrucciones en un lugar de fácil acceso para referencia futura.

General Weighing Operation

1. This scale operates on 2 CR2032 Lithium batteries (included). There is a plastic strip under the Lithium battery cover to prevent battery drain in shipping. Remove the strip before continuing with these instructions.
2. Place the scale on a hard, level surface.
3. Press **"ON-TARE"** to turn the scale on. The display first shows " 8888 ", then zero when it is ready for use. If the display does not show zero, press **"ON-TARE"** to reset (tare) the scale to zero.
4. Your scale is set at the factory to weigh in pounds/ounces. To switch between grams (g), ounces (oz), pounds and ounces, (lb:oz) and milliliters (ml), press the **"UNIT"** button.
   Aquatronic® feature to measure liquid ingredients: The Aquatronic® liquid measure feature is suitable for all water based liquids, including wine, milk, stock, cream etc. **Note: Oils have a lower specific gravity, which will result in a volume reading of approx +10%. If measuring oils by volume on this scale, please adjust for this accordingly.**
5. Place the item to be weighed on the center of the platform. The weight will display. As you add weight, the weight displayed increases.
6. The scale will turn off automatically after 1 minute of non-use or if there is no change in weight after 3 minutes. Press and hold **"ON-TARE"** to turn the scale off manually.

Battery Replacement

1. Your Taylor® scale is equipped with a low battery indicator. It will display **"LO"** or readings will grow dim or become irregular if the batteries needs replacement.
2. Open the battery compartment on the bottom of the scale.
3. Remove the old batteries. Place the new batteries into the battery compartment with the "+" signs showing.
4. Replace the battery compartment cover.

NOTE: Please recycle or dispose of batteries per local regulations.
WARNING: Batteries may pose a choking hazard. Do not let children handle batteries.

Tare Operation

You may wish to weigh ingredients a bowl or other container (not included). In this case, you will need to tare, or offset, the weight of the bowl so that only the weight of the ingredients is displayed.

1. Choose a container that will safely balance on the platform without tipping or falling. Do not use a heavy container, as this might reduce the maximum capacity of the scale.

Tare Operation (Cont.)

2. While the scale is off, place the empty container on the scale platform. Turn the scale on. The display will show zero. The weight of the container has been zeroed out.
3. Add the ingredient to be weighed. The weight of the ingredient alone will display.
4. The weight of additional ingredients may be tared out as well. For example, if a recipe calls for ½ lb rice and ½ lb beans, place the rice into the bowl. Once the correct amount of rice is weighed, press "ON-TARE" until the display is reset to zero. Add the ½ lbs of beans. Both ingredients have been accurately weighed in the same bowl.
5. When weights have been tared out, the display will show a negative number when the items are removed from the scale. To reset the scale back to zero for a new measurement, press "ON-TARE" until the display resets to zero.

Precautions

1. Clean exposed parts with a soft, slighily damp cloth. To remove stains, use a mild soap. Never use detergents, excess water, treated cloths, harsh cleaning agents, or sprays. Avoid contact with acids, such as citrus juices.
2. Do not tamper with the scale's internal components. Doing so will invalidate the warranty on this unit and may cause damage. The scale contains no user-serviceable parts
3. Although your scale is designed to be maintenance-free, it contains sensitive electronic parts. Avoid rough treatment. Treat it with care to ensure the best performance.
4. This scale is intended for home/consumer use only. It is not intended for commercial or medical use.
5. This scale is designed to read weights up to 11 lb/176 oz/5000 g/5000 ml. To prevent damage, do not place more than 11 lb/176 oz/5000 g/5000 ml on it.
6. Do not store scale where you store cleaning chemicals. The vapors from some household products may affect the electronic components of your scale. Do not store scale on its side.
7. This scale is an extremely sensitive weighing device. In order to prevent run down of the battery, do not store anything on the scale.
8. Do not dispose of batteries in fire. Batteries may explode or leak. Do not mix old and new batteries. Remove the batteries if the scale will not be used for a long period of time.
9. Unstable Warning: Should **"unSt"** appear on the display, this indicates the scale is unstable. Place the scale on a hard, level surface during use.
10. Overload Warning: Should **"EEEE"** appear on the display during a weighing, this indicates that the maximum weighing capacity of the scale has been exceeded. Remove the weight immediately; otherwise, permanent damage could occur.

Ten (10) Year Limited Warranty

Salter® warrants this product to be free from defects in material or workmanship (excluding batteries) for ten (10) years for the original purchaser from date of retail purchase. It does not cover damages or wear resulting from accident, misuse, abuse, commercial use, or unauthorized adjustment and/or repair. If service is required, do not return to retailer. Should this product require service (or replacement at our option), please pack the item carefully and return it prepaid, along with store receipt showing the date of purchase and a note explaining reason for return to:

Garantie limitée de dix (10) ans

Salter® garantit que ce produit (à l'exclusion de la piles) à dix (10) ans pour l'acheteur original contre les défauts de matériaux et de main d'oeuvre à partir de la date d'achat au détail. Elle ne couvre pas les dommages ou l'usure suite à un accident, une mauvaise utilisation, tout abus, utilisation commerciale ou réglage interdit et/ou réparation interdite. Si l'appareil doit être réparé, ne le retournez pas au détaillant. Si ce produit doit être réparé (ou remplacement à notre discrétion), veuillez l'emballer avec soin et le retourner à frais prépayés avec la facture du magasin indiquant la date d'achat et une note expliquant la raison du retour à l'adresse suivante:

Garantía limitada de diez (10) años

Salter® garantiza este producto contra defectos en los materiales y en la mano de obra (excepto las baterías) durante diez (10) años para el comprador original a partir de la fecha de compra original. No cubre daños ni desgastes que sean consecuencia de accidentes, uso inadecuado, abuso, uso comercial, ni ajustes y/o reparaciones no autorizadas. Si necesita mantenimiento, no la devuelva al vendedor minorista. Si este producto requiere mantenimiento (o cambio a nuestro entender), sírvase empacar el artículo cuidadosamente y envíelo con el franqueo pagado, junto con el recibo de la tienda en el que aparezca la fecha de compra y una nota explicando el motivo de la devolución a:

Salter Housewares
2220 Entrada Del Sol, Suite A
Las Cruces, New Mexico 88001 USA

There are no expressed warranties except as listed above. This warranty gives you specific legal rights, and you may have other rights which vary from state to state. For additional product information, or warranty information in Canada or elsewhere outside the USA, please contact us through www.salterhousewares.com

Il n'y a aucune garantie expresse sauf celle indiquée précédemment. Cette garantie vous donne des droits précis, mais vous pouvez aussi avoir d'autres droits qui varient d'une juridiction à l'autre. Pour de l'information supplémentaire sur le produit ou sur la garantie au Canada ou ailleurs à l'extérieur des É.-U. veuillez nous contacter par www.salterhousewares.com

No existen garantías expresas excepto las enunciadas anteriormente. Esta garantía le otorga derechos legales específicos y es posible que usted tenga otros derechos que varíen de un estado a otro. Para obtener información adicional sobre el producto, o información de la garantía en Canadá o en otro sitio fuera de los EE.UU., sírvase contactarnos a través de www.salterhousewares.com

©2011 Salter Housewares and its affiliated companies, all rights reserved. Salter® is a registered trademark and When clever meets convenient, that's Living with Salter™ is a trademark of Taylor Precision Products, Inc. and its affiliated companies. All rights reserved.

©2011 Salter Housewares et ses sociétés affiliées, tous droits réservés. Salter® est une marque de commerce déposée et When clever meets convenient, that's Living with Salter™ est une marque de commerce de Taylor Precision Products et de ses sociétés affiliées. Tous droits réservés.

©2011 Salter Housewares y sus compañías afiliadas, todos los derechos reservados. Salter® es una marca registrada y When clever meets convenient, that's Living with Salter™ es una marca registrada de Taylor Precision Products, Inc. y sus compañías afiliadas. Todos los derechos reservados.

Made to our exact specifications in China.
Fabriqué en Chine selon nos spécifications exactes.
Fabricado en China según nuestras especificaciones exactas.
Not legal for trade. • Non légal pour le commerce. • No es legal para uso comercial.